

TABLE OF CONTENTS

	Pages
— TABLE OF CONTENTS	31
— IDENTIFICATION MARKINGS	31
— GENERAL SPECIFICATIONS	31
Engine	31
Reversing-reducing gear	31
— OPERATING	32
Instrument panel	32
Running in	32
Preliminary starting operations	32
Starting up	32
Stopping engine	32
— TECHNICAL ENGINE DETAILS	33
Lubricating system	33
Fuel system	33
Adjusting valves	33
Re-tightening cylinder head	34
Tightening cylinder head	34
Checking injectors	34
Tightness of belts	34
Shaft-line stuffing box	34
Tightening torques	34
Cooling system (Fresh water system - Sea water system)	34-35
Electrical system	35
— TECHNICAL DETAILS :	
Reversing and reducing gear	35
Borg-Warner	35-36
Laying up for winter (Afloat - Ashore - Starting up again)	36-37
— PERIODICAL MAINTENANCE	37
— TROUBLE SHOOTING	38-39
— ELECTRICALS	39
— PERSONAL NOTES	40

IDENTIFICATION MARKS

Page 3

1. Engine unit - 2. Borg-Warner reducing gear - 3. Injection pump.
When entering into correspondence : requesting information ;
ordering spare parts.

The references shown on plates 1-2-3 in the illustration must be stated.

GENERAL SPECIFICATIONS

Page 4

Engine	RC 90 DS
Basic engine	SAVIEM
Type	720
Cycle	4-stroke
Number of cylinders	4
Injection system	Direct type M
Injection advance	23° before TDC
Power output (SAE)	80 HP
Bore	102 mm
Stroke	110 mm
Total cubic capacity	3 600 cm ³
Compression ratio	17.5 to 1
Injection order	1 - 3 - 4 - 2
Injection pressure	175 bars
Tickover speed	700 rpm
Maximum speed :	
No load	3 300 rpm
Under load	3 000 rpm
Cruising speed	2 800 rpm
Lubrication	Under pressure
Cooling	Double circuit with heat exchanger
Overloading	Automatic
Maximum slope angle	15°
Direction of rotation	

Page 5

Make	Borg-Warner.
Type	Hydraulic 71 C.

Reduction ratios :

Anti-clockwise direction (1) ..	1/1 - 1/1.5 - 1/2 - 1/2.5 - 1/2.9.
Clockwise direction (1)	V/drive 1/1.9.

(1) Propeller rotation is considered seen from the REAR of the boat.

OPERATING

Page 6

• INSTRUMENT PANELS

— Basic module

M. I 12 V : 674 125.
24 V : 674 114.

1. Voltmeter.
2. Hour counter.
3. Oil pressure.
4. Ignition switch.
5. Starter.
6. Pre-heating (if any).
7. Instrument panel lighting.
8. « Stop » switch.
9. Oil pressure warning light.
10. Water temperature warning light.
11. « On » warning light.

— Tachometer

M. II 12 V : 674 112.
24 V : 674 120.

1. Tachometer.
2. } Navigation lights.
3. }

— Water temperature gauge

M. III 12 V : 674 113.
24 V : 674 121.

1. Water temperature.
2. } Navigation lights.
3. }

Note : M. I : Module I.
M. II : Module II.
M. III : Module III.

Using the different modules here shown on the left, the following combinations may be obtained :

ON 12 VOLTS :

N° 1 (utility) : 674 125.
N° 2 : 674 125 + 674 113.

N° 3 (de luxe) : 674 125 + 674 112.
N° 4 : 674 125 + 674 112.

ON 24 VOLTS :

N° 1 (utility) : 674 114.
N° 2 : 674 114 + 674 121.
N° 3 (de luxe) : 674 114 + 674 120 + 674 121.
N° 4 : 674 114 + 674 120.

Pages 7 and 8

• RUNNING IN

Prior to being delivered, the engines are partly run in on RENAULT marine COUACH test benches. During the first 20 hours they are run at the following speed : 2 300 rpm whilst accelerating from time to time for 5 minutes at 2 500 rpm.

For the next 30 hours, the engines can be used at : 2 500 rpm with a few accelerations at 3 000 rpm.

Over and above 50 hours, the engines may be used at any speed.

As a general rule, and for safety reasons, maximum speed should not be maintained for more than one hour.

• PRELIMINARY STARTING INSTRUCTIONS

- Open the sea water inlet valve.
- Switch battery on.
- Check fuel level.
- Using dip gauge, check engine oil level [fig. 1].
- Using plug dip gauge, check oil level in reversing-reducing gear [fig. 2].

- Check the fresh water level through plug [fig. 3].
- Purge the fresh water system (see para. purge and fig.).
- Purge the fuel system (see purge chapter).
- Place reversing gear in neutral.

Note. — It is recommended that the fuel tap should only be closed in case of extreme necessity.

Careful : If the boat has run aground make sure that the strainer is immersed and not clogged.

Page 9

• STARTING UP

When the checks have been done :

- Place the gas control to MAXI.
- Switch on (instrument panel).
- Make sure « STOP » control is not pulled out.
- Press starter button.
- As soon as engine starts, release the button.

Warning : Never press button for more than 4 to 5 seconds when starting. To help starting in cold weather, use a starting agent sprayed into the inlet tube whilst turning the engine over with the starter motor.

• STOPPING ENGINE

- Put reversing lever into neutral.
- Bring engine to tickover and then let it run for a few moments so as to stabilize the temperature.
- Pull the stop control.
- Turn ignition switch off.
- Switch off battery.

TECHNICAL ENGINE DETAILS

• LUBRICATION SYSTEM

Page 10

Engine :

Pressure feed using rotary pump.

Minimum pressure at tickover :

0.5 kg/cm²

Pressure at maximum speed :

3.5 to 4.6 kg/cm² ± 1

System capacity : 9 L.

Sump capacity : 7.5 L.

Filter capacity : 0.5 L.

Cooler capacity : 1 L.

Grade of oil :

Summer : ELF performance 30.

Winter : ELF performance 20.

Filling with oil :

This is done through the filling hole in the rocker cover.

Remove the plug [fig.4].

Pour in the required quantity of oil.

— Wait a few moments for the oil to run down into the sump.

— Check level with dipstick fig.

— Put plug back.

Careful : Do not go beyond maximum level of dip-stick. Too much oil may lead to a loss of power and too much smoke in the exhaust fumes.

Page 11

Draining :

Draining must always be carried out when oil is hot using the drain pump [fig.6].

Oil dip-stick :

This is marked according to the different possible slants of engine. The oil level can be marked as a function of the slant of the chosen engine.

• OIL FILTER [fig.7]

Every 100 hours change the filter element for a new one.

— Slacken off the screw (1).

— Clean the bowl using fuel-oil.

— Check condition of gasket (2) and if necessary, change it.

— Check sleeve tightness.

— Fit parts together making sure gasket is correctly positioned.

• FUEL SYSTEM

The system comprises :

— One or more tanks.

— A dash tank (for twin engines).

— A decanting filter.

— An engine mounted filter and pre-filter.

— A feed pump.

— An injection pump.

— 6 injectors.

— An injector leak return system.

Injector rating 190 bars.

Filling up :

Careful : To avoid draining of the fuel system and condensation in the tank, it is strongly recommended to fill up after the last trip of the day.

Page 12

• PURGING SYSTEM

— Open tank and dash tank cocks :

— Remove the air purge plug from the dash-tank and evacuate air.

— Replace purge plug as soon as fuel flows.

— Slacken off the decanter-pre-filter purge screw.

— Wait until fuel flows and tighten purge screw.

• PURGING FUEL FILTER (fig.8.10.)

— Open purge screw (1).

— Actuate the primer lever (2) on feed pump until fuel runs clear and free of bubbles.

— Close purge screw.

— Slacken filter outlet union (3).

— Actuate feed pump lever until fuel flows bubble-free.

— Retighten the union at the same time actuating the lever.

• PURGING INJECTION PUMP

— Slacken off inlet union [fig. 9].

— Actuate feed pump lever.

— When fuel flows bubble-free, tighten union.

— Same procedure as for return union [fig. 9].

Slacken off injector inlet unions [fig.11]. Turn engine over until fuel flows bubble-free. Tighten unions.

Page 13

• ADJUSTING VALVES

Clearances :

— Inlet : 0.20 to 0.25 } Cold.
— Exhaust : 0.35 to 0.40 }

— Remove rocker cover.

— Adjust rocker clearances in the following manner :

Make valves lap on cylinders	Adjust clearance on cylinders
4	1
2	3
1	4
3	2

Note : Cylinder n° 1 is on Clywheel end of engine.

• RE-TIGHTENING CYLINDER HEAD

This must be done at guarantee service by an R m C agent, when engine is still hot, at 50 hr. of working.

A torque spanner must be used for this operation and after tightening the rockers must be systematically adjusted.

Method :

- Work screw by screw in the order shown fig.
- Slacken screw off 1/4 turn, then :
- Tighten screw to required torque (12 mkg).

• TIGHTENING CYLINDER HEAD

When refitting a cylinder head, tighten the screws in the order shown in fig.

- Three successive tightenings :
- 1 st. tightening : 4 mkg.
- 2 nd. tightening : 8 mkg.
- 3 rd. tightening : 12 mkg.
- Adjust rocker clearances.

Page 14

• CHECKING INJECTORS

Removing :

- Disconnect the injector inlet piping and leak return piping making sure not to bend them.
- Remove injector fixing flanges.
- Extract injectors.
- Have them checked by a R m C dealer.

When refitting :

- Fit a new (annealed) copper gasket.
- Centre and line up the jet in its housing.
- Progressively tighten the lug locking screw with a torque spanner to 3 mkg.

Rinsing oil cooler :

Every 400 hours (or every year) dismantle the cooler.

- Soak the tube-bank for 50 minutes in a detergent solution at a temperature of 90°.
- Rinse with water.
- Dry the tube-bank well.
- Fit the cooler changing the gaskets if necessary.

• BELT TIGHTNESS

This should be checked after 20 hours of working and there-after every 100 hours.

Alternator belt :

To be checked after 20 hours of working and then every 100 hours.

Alternator belt :

- Slacken off fixing screws (1) (2) [fig. 13].
- Tighten belt by acting on the tightening screw (3).
- Re-tighten the screws in order (1) (2) [fig. 13].

Page 15

Sea-water pump belt :

- Slacken off nuts (4) (5) and (6) fig.13
- Tighten belt by pivoting pump in direction of arrow fig.13
- Retighten screw (4) at the same time keeping belt taut.
- Retighten screws (5) and (6).

Careful : The belts must not be too tight so as not to put too much strain on the bearings.

• PROPELLER SHAFT STUFFING BOX

— After tightening stuffing box you must always check that shaft turns freely in neutral position. Slight seepage is advisable to ensure proper stuffing lubrication.

• TIGHTENING TORQUES

Crankshaft bearing cap screws	17 to 18 mkg
Connecting rod nuts ..	9.5 to 10 mkg
Cylinder head bolts	12 mkg × 3 off
Engine flywheel screws.	20 to 22 mkg
Rocker assembly nuts ..	8 mkg
Oil sump/cylinder block	2.5 mkg
Oil sump drain plug ..	3 mkg
Inlet manifold fixing bolts	1.5 mkg
Exhaust fixing bolts ...	5.1 mkg
Cylinder head cover nuts	0.45 mkg
Injector holder clamp ..	3 mkg
Injector	6 to 8 mkg
Crankshaft counter-balance screws	11 mkg
Crankshaft nuts	41 to 43 mkg
Feed union	1 to 1.5 mkg

Page 16

• COOLING SYSTEM

Dual system with heat exchanger.

Fresh water system :

Capacity : 15 litres.

Filling :

Through heat exchanger filling cap [fig.14].

- Retighten purge plug.
- Start engine and top up level in heat exchanger.

Note : We advise you to use the water-anti-freeze mixture all the time. However, if no anti-freeze is used, 1/2 litre of anti-rust oil must be added to protect the cooling system (eg. SARROL type 0 soluble oil).

Page 17

Draining :

- Open engine block drain valve [fig.15].
- Remove exchanger drain plug [fig.16] or remove exchanger caps, as needs exchanger filler cap.
- Remove engine oil cooler drain plug [fig.17].
- Unscrew exhaust pipe drain plug [fig.18].

Page 18

Sea water system :

When working, the sea water is constantly renewed. It is drawn in by the circulating pump and then goes through the heat exchanger, the (BORG-WARNER) reversing gear oil cooler and is then pumped out through the water injection elbow.

Draining :

- Open drain plugs :
 - On heat exchanger fig.19 (or if needs be, remove exchanger cap).
 - On reversing gear oil cooler [fig.20].
 - On water injector elbow [fig.21].
 - On splash exhaust box.

- Close sea water inlet valve.
- Disconnect sea water pump piping [fig.22].
- Actuate the starter once or twice (with « STOP » control pulled out) to clear the pump of water.

Page 19

• ELECTRICAL SYSTEM

Checking battery :

- Unscrew filler caps of each element ;
- Check that level of electrolyte is between 15 and 20 mm above plates ;
- If necessary, top up with distilled water.

Warning : Never add acid.

Checking alternator :

The alternator must never be lubricated. Any checks or overhauling must be carried out by an authorized agent.

Checking starter :

- Periodically check tightness of fixing bolts to block and electrical connexions.

Warning : To avoid any serious deterioration of electrical equipment, the following instructions must be followed :

- Switch off engine before disconnecting battery ;
- Insulate battery before charging ;
- Check connexions to regulator ;
- Never disconnect regulator when generator is working ;
- Check that regulator is earthed ;
- Check that generator is connected to battery ;
- Never earth the « EXC » terminal on regulator, nor the lead connecting it to the « EXC » generator terminal.

TECHNICAL DETAILS

Page 20

• BORG-WARNER REVERSING GEAR

Model : hydraulic.

Type : 71 C.

Reduction ratio : 2.1 to 1, 1.5 to 1, etc. Transmission is with a quick-acting disc clutch.

The clutch is worked by moving the gear-change lever either forwards or backwards which actuates a hydraulic distributor. The assisted pressure is supplied by an oil gear pump.

Hydraulic System :

Grade of oil : ELF MATIC G.

Capacity : 2.6 l approx.

Note. — It is possible to adapt, as an option, reverse gears of same make but having different ratios, or a V DRIVE type reducing-reversing gear. Depending on the type of V DRIVE, the oil capacity may be 3.8 l or 4.8 l approx. (instead of 2.6 l for current models).

Checking oil level [fig.23].

- Completely unscrew rod 1, remove dip-stick 2 and wipe ;
- Take reading by pushing dip-stick home ;
- Check that oil level is situated between the mini. and maxi. marks ;
- Top up if necessary and screw back dip-stick.

Entering into service for first time :

When entering into service for first time (or when completely dismantling unit), proceed in the following manner :

- Fill the reversing gear to maxi. level ;
- Start engine to fill the oil system ;

- Switch off after a few moments ;
- Top up oil level.

Warning : Too much oil could have an influence on the neutral position of unit. The maximum level on the dipstick must not be gone beyond in any circumstances.

Page 21

Draining :

- Remove filling plug and unscrew drain plug (1) [fig.24].
- Replace drain plug and filter ;
- Carefully clean filter ;
- Fill up ;
- Screw filling plug back in ;
- Turn engine over a few minutes to ensure system is filled ;
- Switch off engine ;
- Check level and top up if needs be.

Note. — If drain plug is not accessible, use a syringe for draining.

Checking Borg-Warner Reversing Gear control lever [fig. 25].

Bilge water splashing between the control lever and bearing face can sometimes make the lever difficult to move.

To overcome this, you must :

- Slightly unscrew the control lever retaining nut ;
- Clear lever from bearing face by approx. 2 mm ;
- Using a brush, apply engine oil or grease to the lever and bearing interfaces ;
- Retighten retaining screw.

Pages 22 and 23

• LAYING UP FOR WINTER

Sea water freezes at — 6°C.

To avoid any risk of freezing, which would damage the engine, it is necessary to complete the following operations before the winter period arrives :

Afloat :

- Drain the fresh water system (see draining chapter p.16).
- Replace fresh water with a mixture of water and anti-freeze in the following proportions :
 - 15 % for protection to — 10°C (approx. 2.5 l of anti-freeze).
 - 22 % for protection to — 20°C (approx. 3.5 l of anti-freeze).
 - 35 % for protection to — 30°C (approx. 5.5 l of anti-freeze).
- Close sea-water inlet valve.
- Drain sea-water system.
- Tighten the stuffing box to make it water-tight.
- Spray oil into the inlet pipe ;
- Remove injectors and put in 5 cm³ of storage oil into each cylinder.
- Refit injectors.
- Plug all openings with either oil paper or greasy rags.
- Remove the battery and electrical accessories and give them to a R m C agent who will carry out maintenance work on them.

Ashore :

When the boat is to be laid up, you should :

- Remove the sea-water inlet piping [fig. 22].
- Connect a fresh water pipe.

- Drain engine oil.
- Fill up with ELF STOCKAGE oil.
- Let engine tick over for approx. 30 minutes.
- Switch off engine and drain off storage oil.
- Drain off the sea-water system (see chapter p.18).
- Drain off fresh water system (see chapter p.17).
- Spray oil into inlet tube.
- Take injectors out and put in 5 cm³ of storing oil in each cylinder.
- Put injectors back in.
- Plug all openings using oil paper or greasy rags.
- Remove the battery and electrical accessories and give them to a R m C agent who will carry out maintenance work on them.

Very Important :

In all circumstances when the engine will not be run for some time (laying up for winter, storage) the following instructions must be followed for the fuel system :

- Close tank cocks ;
- Change fuel filter elements ;
- Disconnect feed pipe and plunge it into a container of clean fuel placed under load with relation to the engine ;
- If necessary purge the system ;
- Let engine run for approx. 10 minutes ;
- Reconnect the fuel inlet.

• PUTTING INTO SERVICE

- Remove the oil paper (or greasy rags) from all openings ;
- Drain storage oil ;
- Fill up with engine oil ;

- Fill up with fuel ;
- Purge fuel system ;
- Fill fresh water system, and add half a litre of anti-corrosive oil (eg. SAR-ROL, type : 0) ;

- Re-fit the battery and electrical accessories ;
- Untighten the shaft stuffing box (the shaft should turn freely by hand).
- Inspect engine completely prior to starting.

Important :

Before starting engine do not forget to open the sea-water inlet cock.

PERIODICAL MAINTENANCE

OPERATIONS	At each time of starting	After first 20 hours	After first 50 hours	Every 100 hours	Every 200 hours	Every 400 hours	Every 1 000 hours
Engine oil level	X						
Reversing gear oil level	X	X					
Fuel level	X						
Fresh water level	X						
Drain decanter, decanter filter		X	X	X			
Drain engine oil		X	X	X			
Drain reversing gear oil						X	
Electrolyte level		X	X	X			
Check tightness of belts		X		X			
Change oil filter element		X			X		
Change fuel filter elements		X					
Clean battery terminals						X	X
Retighten cylinder head			X				
Adjust valves			X				
Clean decanter filter			X	X			
Injector calibration and jet checking						X	
Cleaning turbo compressor						X	
Retightening oil filter			X				
Retightening fuel filter			X				
Retightening push-rod access cover			X				
Retightening sump			X				
Retightening feed pump			X				
Retightening injection pump			X				
Retightening inlet manifold			X				
Retightening exhaust manifold			X				
Check condition of decanting bowl of fuel filter ..					X		
Purge reservoir(s)						X	
Rinse oil heat exchanger							X

NOTE : The service operations intended for 100 hr., 200 hr. and 400 hr. must be systematically carried out every year if the engine does not reach the amount of hours required.

TROUBLE SHOOTING

TROUBLE	CAUSES	REMEDIES
<i>Black smoke in exhaust.</i>	<p><i>Bad combustion.</i></p> <p><i>Air deceleration at inlet.</i></p> <p><i>Exhaust blocked.</i></p>	<p><i>Have the injectors as well as the injector pump checked by a specialist.</i></p> <p><i>Check condition of air filter.</i></p> <p><i>Check exhaust outlet.</i></p> <p><i>Check thermostart plug.</i></p>
<i>Engine won't start.</i>	<p><i>Out of fuel.</i></p> <p><i>Fuel not coming through properly.</i></p> <p><i>Fuel filters blocked.</i></p> <p><i>Air in the fuel system.</i></p> <p><i>Starter won't work.</i></p> <p>— <i>Faulty contact.</i></p> <p>— <i>Battery discharged.</i></p>	<p><i>Fill up and purge system.</i></p> <p><i>Purge system.</i></p> <p><i>Change filter elements.</i></p> <p><i>Purge system.</i></p> <p><i>Check connexions and purge system.</i></p> <p><i>Have starter checked.</i></p> <p><i>Check tightness of battery terminals. Re-charge batteries.</i></p>
<i>Engine difficult to start.</i>	<p><i>« STOP » control stays in intermediate position.</i></p> <p><i>Air in fuel system.</i></p> <p><i>Lack of compression.</i></p> <p><i>Insufficient flow from fuel pump.</i></p>	<p><i>Check and push in the « stop » control.</i></p> <p><i>Purge system.</i></p> <p><i>Check compression ratios.</i></p> <p><i>Check fuel pump.</i></p>
<i>Engine runs irregularly.</i>	<p><i>Small quantity of air in fuel system.</i></p> <p><i>Injectors fouled up.</i></p> <p><i>Water or dirt in system.</i></p> <p><i>Rocker clearances wrong.</i></p> <p><i>Pump maladjusted.</i></p>	<p><i>Check unions and piping. Purge system.</i></p> <p><i>Remove, clean and adjust injectors.</i></p> <p><i>Purge decanter and system.</i></p> <p><i>Adjust rocker clearances.</i></p> <p><i>Check timing and controls.</i></p>
<i>White smoke in exhaust.</i>	<p><i>Faulty cylinder head gasket.</i></p> <p><i>Lack of injection advance.</i></p>	<p><i>Change gasket.</i></p> <p><i>Check injection pump timing.</i></p>
<i>The oil and water warning light comes on.</i>	<p><i>Out of water.</i></p> <p><i>Out of oil.</i></p>	<p><i>Switch engine off immediately.</i></p>

TROUBLE	CAUSES	REMEDIES
Water and oil warning signal sounds. Engine becomes abnormally hot.	Inlet strainer clogged or dirty. Stretched or broken belt. Faulty water pump rotor. Electrolytic zinc comes out and blocks piping. Faulty thermostat.	Check oil level. Check fresh water level. Fill up. Check sea-water flow rate. Clean inlet strainer. Change or tighten belt. Change rotor. Remove zinc and fit a new one. Momentarily remove and replace.
Engine won't reach required n° of revs.	« STOP » control lacks stroke.	Adjust « STOP » control stroke.
Engine runs unevenly.	Air leak.	Check fuel system and purge it.
Engine is noisy.	Adjust rocker clearances. Check injection pump adjustment.	Check injectors. Check pump timing. Check valve springs.
Reverse gear control lever difficult to move (BORG-WARNER). No reverse gear neutral position (BORG-WARNER).	Oxidisation between lever and bearing face. Too much oil. Faulty clutch.	Slacken fixing nut. Pull lever out slightly (2 mm) and oil. Drain off oil to correct level. Have reverse gear checked.

ELECTRICALS

For the wiring diagram, depending on the type of engine, refer to dwgs.

N° 674 134 — Engine wiring 12 V.

N° 674 135 — Engine wiring 24 V.

N° 674 125 — Module I instrument panel wiring 12 V.

N° 674 114 — Module I instrument panel wiring 24 V.

N° 674 112 — Module II instrument panel wiring 12 V.

N° 674 113 — Module III instrument panel wiring 12 V.

N° 674 120 — Module II instrument panel wiring 24 V.

N° 674 121 — Module III instrument panel wiring 24 V.

PERSONAL NOTES
