


# MINIMUM SYSTEM WIRING BASIC INSTALLATION

fig 7



How to increase the number of battery banks charged from a Pro Alt using a Pro Split this can be done in any configuration

