

## TRAXAR Features

### BUILT-IN ANTENNA

Hold parallel to the ground.

### DISPLAY SCREEN


Displays data and menu option lines.

#### • Valid Position Icon

When solid, position data is valid. When blinking, unit is not tracking enough satellites to compute accurate position.\*

#### • Alarm Icon

When icon blinks, an alarm has been tripped.\*\*



### OPTION BUTTONS (Soft Keys)

The function of each button can change from screen to screen. Used to enter and display information.

### FUNCTION KEYS (Hard Keys)

Function keys can be used at any time while any screen is displayed.

#### • Light

Turns lights on and off.

#### • Mark

Enables you to store current location.

#### • Quit

Enables you to leave an operation when you are finished, or stop the current activity and return to a previous screen.

#### • Power

Depress and hold to turn unit on and off.

\*Refer to Menu Option 7 to check satellite status.

\*\*Refer to Menu Option 9 to determine which alarms have been set.

## TRAXAR Menu Options

- 1. Position** – Display latitude, longitude and altitude of current position. From the Position screen you can display navigation screens or select a waypoint or route screens. Q1 in upper right corner defines quality of satellite reception. (Q1 best reception, Q4 weakest reception.)
- 2. Select Waypoint** – Pick an existing waypoint as your destination. Provides access to navigation screens.
- 3. Select Route** – Pick an existing route. Provides access to navigation screens.
- 4. Waypoint Directory** – Find, create, alter, copy or delete waypoints.
- 5. Route Directory** – Find, create, alter or delete routes. Select existing waypoints in the Waypoint Directory to define your route.
- 6. Configuration** – Change operating settings; for example, distance reported in miles vs. kilometers.

**7. Satellite Status** – Display satellite reception information.

**8. Help Utilities** – Describe options, abbreviations and functions.

**9. Alarms** – Display list of alarms that are set.

## Entering Names and Selecting Options

When a screen with arrow and **ENTER** buttons appears, use these buttons to enter names and numbers, move from field to field, or select or store information.

▶ Moves the cursor to the next position.

▲ ▼ Scroll through numbers or letters.

**ENTER** Stores information and moves to the next field or screen.