

ZJHB0408

BA01

C07

LUB. OIL PRESSURE SWITCH AND GAUGE
MANO. CONTACT PRESSION D'HUILE ET MANOMETRE
OELDRUCKSCHALTER UND OELDRUCKMANOMETER
MANO. E INTERRUOTTORE PRESSIONE OLIO
TRANSMISOR E INDICADOR DE LA PRESSION DE ACEITE LUB.


2 2848A042 1 Switch

3 2431131 2 Plug

PLATE A
PLAQUE A
PLATTE A
PIASTRA A
PLACA A

Schalter
Interruptor
Verschli stopfen
Tapon

Interrupteur
Interruttore
Bouchon
Tappo



B9600 ZJHB-003-A